



Rectifiers, Fast Recovery

1.0 Ampere 200 to 1000 Volts

I_O (AMPS)	1.0
@ T_A (°C)	25
I_{FSM} (AMPS)	30
CASE	  SMA
V_{RRM} (VOLTS)	
200	CMR1F-02M
400	CMR1F-04M
600	CMR1F-06M
1000	CMR1F-10M

V_F MAX @ I_F = I_O	1.3V
--	------

I_R MAX @ V_{RRM}	5.0μA
t_{rr} (200V)	150ns
t_{rr} (400V)	150ns
t_{rr} (600V)	250ns
t_{rr} (1000V)	500ns