



SONY RADIO TR-86

- C1 - Sez. Ant. Cond. Var. - PVC-2BM
- C2 - Comp. Sez. Ant. Cond. Var. - PVC-2BM
- C3 - Comp. Sez. Osc. Cond. Var. - PVC-2BM
- C4 - Sez. Osc. Cond. Var. - PVC-2BM
- C5 - 5000 PF
- C6 - 10000 pF
- C7 - 10000 pF
- C8 - 180 pF
- C9 - 5000 pF
- C10 - 20 mF

- C11 - 2 pF
- C12 - 180 pF
- C13 - 30 mF
- C14 - 10000 pF
- C15 - 2 pF
- C16 - 180 pF
- C17 - 20000 pF
- C18 - 5 mF
- C19 - 1000 pF
- C20 - 20 mF
- C21 - 5 mF
- C22 - 30 mF
- C23 - 20 mF
- C24 - 5000 pF

- L1 - Bobina antenna LA/461/6E
- L2 - Bobina Oscill. LO/002/Q
- MF1 - Media Freq. LI - 008 - AP
- MF2 - Media Freq. LI - 008 - BP
- MF3 - Media Freq. LI - 008 - CP
- T1 - Trasn. Accopp. TI - 002 - 03
- T2 - Trasn. Uscita TX - 002 - 03
- R1 - 820 ohm
- R2 - 56 Kohm
- R3 - 10 Kohm
- R4 - 2,2 Kohm
- R5 - 2,2 Kohm
- R6 - 82 Kohm
- R7 - 33 Kohm
- R8 - 470 ohm

- R9 - 820 ohm
- R10 - 18 Kohm
- R11 - 75 Kohm
- R12 - 470 ohm
- R13 - 5 Kohm pot. con. int.
- R14 - 1,5 Kohm
- R15 - 56 Kohm
- R16 - 10 Kohm
- R17 - 2,2 Kohm
- R18 - 10 Kohm
- R19 - 56 Kohm
- R20 - 10 Kohm
- R21 - 680 ohm
- R22 - 5 ohm
- R23 - 220 ohm

- R24 - 220 ohm
- R25 - 5,6 Kohm
- R26 - 22 ohm
- R27 - 22 ohm
- R28 - 270 ohm
- TR1 - 2T7
- TR2 - 2T7
- TR3 - 2T7
- TR4 - 2T7
- TR5 - 2T6
- TR6 - 2T6
- TR7 - 2T6
- TR8 - 2T6
- DG1 - 1T2
- DG2 - 1T5